INTREPID UDG SAFETY GATE

INSTALLATION GUIDE

SIZE:

UDG-37

UDG-32

UDG-27

UDG-22

1085

960

830

705

114

⚠ The blade of the gate must be long enough to contact, and extend past, the opposite guardrail post by 50 mm or more from the center line of the support block.

MIN. 50

610

HINGE
2x M12 BOLTS

in | 22 | 27 | 32 | 37

INTREPID IND. INC.
www.intrepidindustries.com

mm | 560 | 690 | 820 | 950

SUPPORT BLOCK
1x M12 BOLT

Opening between angle guardrail

4 Standard sizes

22"/560 mm   27"/690 mm
32"/820 mm   37"/950 mm

35 typ.

88

159

100

MIN. 45

⚠ Support block is mounted below the top rail of the gate to prevent vertical deflection. **It should not make contact with the gate or interfere with it swinging closed.** Field installations: simply mount the the block at least 45 mm **below** the closed bar.

⚠ Use plastic washer only to compensate angle thickness on angle guardrails.
Do not use with additional installation kits.